




Derating Instructions for SWTCH Home Charging Program


Joint Tech EV Charger EVL007

Video walkthrough Derating the SWITCH Home Charger:




Derating the **SWITCH** Home Charger

Step 1: Open the Charger Case



Step 2: Derate the EV charger


(NEMA Plug versions)



Switch Setting Number	0	1	2
Maximum Output Current	16A	32A	40A

Step 2: Derate the EV charger

(Hard-wired versions)



Switch Setting Number	0	1	2	3	4	5	6	7	9
Maximum Output Current	16A	32A	40A	48A					